

**Core Key Extractor**

Part Number **50113**

For the removal of valve cores from accumulator bladder stem

**Charging Adaptor**

MWP – N/A

Part Number **10712**

Used for charging 0.302x14TPI (U.S. Style) gas valves

**OFC Gas Valve**

Part Number **10053-S03**

Standard ¼” BSPP gas valve found in OFC accumulators (4 litre and up)

**Charging Adaptor**

MWP – 600 Bar

Part Number **10709**

Used for charging 5/8” UNF (European Style) gas valves

**Charging Head (c/w Gauge)**


Working Pressure – 345 Bar

Burst Pressure – 1380 Bar

Test Pressure – 414 Bar

P/N 10500-XX (specify Gauge Pressure)

Provided with ¼” BSPP connection to suit OFC



**Nitrogen Cylinder Adaptors**

Part Number

**OFC100 + OFC101** ( Picture shows superseded model ! )

Used to connect direct from Nitrogen gas bottle to the charging hose. OFC recommend the use of a Nitrogen regulator, in which case this component is not used

**OFC Gas Valve Cores**

Part Number **43274-099**

Standard valve core found in smaller OFC accumulators. Rated to 400 Bar

**Charging Head Bleed Valve**

**Not Available as a spare**

Supplied separately for storage reasons only, the bleed plug must be fitted to the charging head prior to operation. See OFC precharge instructions for installation details

**Charging Hose**

Part Number **50096-099**

2 metre hose ¼” BSPP for connection between Nitrogen Cylinder Adaptor or Regulator and the Charging Head

The Universal Charging Kit **105CK-XX** is supplied in a lightweight portable attaché case. This kit allows the Nitrogen precharging of a large range of accumulators.